



CARE & MAINTENANCE

Cleaning

- For regular cleaning, mild soap and water on a soft cloth will do. Rinse with clean water after washing.
- Minor graffiti (paint, crayon, felt tip markers, etc) can typically be removed with Windex or Bleach or by using organic solvents, such as:

Simple Green - 800.228.0709, www.simplegreen.com

Goof Off - 800.398.3892, www.gooffstainremover.com

Graffiti Solutions - 800.891.0091, www.graffitisolutions.com

- Very stubborn graffiti or staining agents may require use of stronger solvents. These stains can be removed using turpentine, 100% mineral spirits, isopropyl "rubbing" alcohol, WD-40 or MEK (methyl ethyl ketone). Pre-clean the panel to remove any surface particles that may become abrasive when wiping the surface. Use a soft cloth and follow cleaning agents procedure with a detergent rinse and water rinse. If you are not satisfied with the result of the cleaning, repeat the procedure until the stain is removed.
- Do not leave any cleaning agent on for more than a minute.

Maintenance

- To maintain a fresh look edges can be treated with a polymer auto wax or a liquid sealant, such as Thompson's® WaterSeal® Waterproofer Plus Clear Wood Protector, on an annual basis. This helps maintain the core color and protects the edge finish, but is not necessary for longevity or warranty purposes.
- Minor blemishes, nicks, rub marks, burns and light scratches can be concealed using a polymer based surface treatment such as Meguiar's PlastX.
- Proper care and maintenance of your iZone Imaging CHPL graphic panels will ensure the highest quality appearance of function of the product over the expected life of the product.