



CARE & MAINTENANCE

CLEANING

- For regular cleaning, mild soap and water on a soft cloth will do. Rinse with clean water after washing.
- Minor graffiti (paint, crayon, felt tip markers, etc) can typically be removed with Windex or Bleach or by using organic solvents, such as:
 - **Simple Green** – 800.228.0709, www.simplegreen.com
 - **Goof Off** – 800.398.3892, www.gooffstainremover.com
 - **Graffiti Solutions** – 800.891.0091, www.graffitisolutions.com
- Very stubborn graffiti or staining agents may require use of stronger solvents, These stains can be removed using turpentine, 100% mineral spirits, isopropyl “rubbing alcohol”, WD-40 or MEK (methyl ethyl ketone). Pre-clean the panel to remove any surface particles that may become abrasive when wiping the surface. Use a soft cloth and follow cleaning agents procedure with a detergent rinse and a water rinse. If you are not satisfied with the result of the cleaning , repeat the procedure until the stain is removed.
- Do not leave any cleaning agent on for more than a minute.

MAINTENANCE

- To maintain a fresh look edges can be treated with a ploymer auto wax or a liquid sealant, such as Thompson’s® WaterSeal® Waterproof Plus Clear Wood Protector, on an annual basis. This helps maintain the core color and protects the edge finish, but is **not** necessary for longevity or warranty purposes.
- Minor blemishes, nicks, rub marks, burns, and light scratches can be concealed using a polymer based surface treatment such as Meguiar’s PlastX.
- Proper care and maintenance of your iZone Imaging CHPL graphic panels will ensure the highest quality appearance and function of the product over the expected life of the product.